

The Shepherd Auto Sheep Feeder

www.thundervalley.com.au

Ph: 0428 771105 email: Justin.dunn@thundervalley.com.au

The Shepherd Auto Feeder Safety Information

Feeder Risk Warning

1. This feeder contains a rotating auger that has the potential to cause harm and injury.
2. The feeder is designed to be operated by one person only. Bystanders must not touch the feeder during operation. Under no circumstances are children to be allowed access to the feeder.
3. This feeder contains electrical components. Potential risk of electrical shocks.
4. Always isolate and disconnect the battery when conducting maintenance or working on the feeder.
5. This feeder can start up without notice when in operation. It contains automated controls.
6. Under no circumstances is the auger to be touched or handled without the power disconnected. Do not place fingers inside the auger casing holes.

Training and Competence

1. Only trained / competent people are to operate the feeder.
2. Training and staff induction programs must be conducted prior to operating the feeder. Training must include acknowledgment of safety risks and potential hazards.
3. Prior to operation all personnel must read the safety information and operation guide.
4. Always ensure the main drive is isolated when calibrating the feeder and sensor.

Installation and Warranty

This feeder is to be installed by authorised personnel only. Do it yourself installations are not recommended. Thunder Valley takes no responsibility for injury or damage for unauthorised installations.

Thunder Valley provides a parts replacement warranty for a period of 6 months. Labour and associated costs are not included.

The Shepherd Auto Feeder